





# ELLO M

## USER MANUAL



1. The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.
2. No supplied water-proof box, installation should be advised by qualified professional.
3. The external flexible cable can not be replaced. If the cable is damaged, the luminaire should be discarded.


**1**

**2**

**3**

**4**
**Notice:**

1. This fixture works under condition of AC220V -240V /50HZ power input
2. Don't replace any accessory under working in order to avoid falling, electric shock or fire, etc.
3. Ensure a distance of 75mm away from the fixture for the sake of air ventilation and their use should obey all fire regulations.  
The distance between the fixture and the lighted object must be 800mm at least.
4. Don't touch the lamp when in use.
5. Don't be covered by adiabatic material at any time.
6. Please refer to qualified engineer if any other questions about the manual.

**Instruction:**

1. Turn off the power supply.
2. Turn the rotate handle and switch knob to "OFF" position and put the adaptor into Track (See picture 1)
3. Turn the rotate handle to the other side of the adaptor to lock in the track. (See picture 2)
4. Choose the phase channel, turn to 1phase, 2phase or 3 phase, then push the switch knob to "ON" position. (See picture2~3)
5. Installation Completed (See picture 4)